

FIG.1




FIG. 2




FIG. 3




FIG. 4




FIG. 5




FIG. 6

550

setting

563

setting of connected device

562

Select maker and machine type of connected device

561

display remote controller name

BS digital

full size 9 characters

up to half size 18 characters

Maker

not set
Shinagawa Denki
Umeshita Denki
Nageshiba
Medachi
Mitsuaoi
Bikuta

Maker

video-5
video-6
BS digital
digital CS-1
digital CS-2
digital CS-3
cable TV

541

In order to operate device with remote controller, set AV mouse

FIG.7




FIG. 8

9/15




FIG. 9

10/15




FIG. 10

11/15




FIG. 11




FIG. 12




FIG. 13

14/15




FIG. 14




FIG. 15